

## Thank you for purchasing a TOPFIELD HD RECORDER

You can enhance the features by updating the firmware as follows.

### How to update the firmware on TF7100HDPVRt (use the USB stick provided)

1. Turn **ON** HD PVR.
2. Press the **MENU** button on the remote.
3. Scroll down to **INSTALLATION** and press the **OK** button on your remote.
4. Scroll down to **TRANSFER FIRMWARE** and press **OK** button on your remote.
5. Select **UPDATE FROM USB** then press the **OK** button on your remote.
6. A **CAUTION** pop up screen will appear, at this moment Connect your USB stick to the back of the PVR.
7. Using the **V-** button on your remote select **YES** on the screen and then press the **OK** button to commence the upgrade.

The PVR will automatically prepare to update and your TV screen may go to a black screen while the upgrade is take place. On the front display of the PVR it will display UPDATE, please be patient as this may take a few minutes.

After the update is complete the PVR will go back to the previous channel. We strongly recommend doing a **FACTORY RESET** and then a **SERVICE SEARCH** via the **INSTALLATION** menu. This will refresh the channels and will ensure smooth running of the new software. Please refer to the instruction manual for more information on doing a **FACTORY RESET** and a **SERVICE SEARCH**.

For further information or any questions you may have please contact:

**Topfield Service Department on 1300 766 440**